




Ultrasound Solutions

PRICE CATALOGUE

Kits, Accessories and Spare Parts



2024

Products pictures are not contractual.
Prices and product availability are subject to change without notice.
Please contact us if you need informations about a discontinued product,
part or accessory.

SDT International sa-nv
Bd de l'Humanité 415 • B-1190 Brussels (Belgium) • Tel: +32(0)2 332 32 25
email: info@sdtultrasound.com
www.sdtultrasound.com

Content

Basic Kits

• SDT340	4
• SDT340 TankTest	5
• SDT270	5
- SDT270 Keys and Upgrades	6
• SDT200	7
• LUBExpert	8
- LUBExpert Keys	9
• LUBExpert ON-GUARD	9
• Checkers Range	10
- Checkers Accessories	12
• Online4US	12
- Online4US Sensors	15
- Online4US Sensors Cables	16
• CRY SOUND	18
• Vigilant	20
- Vigilant/RSC Cables	21
• Software Licenses	31
• Mobile Apps	33

Accessories

• Flexible Sensors	33
- Flexible Sensors Accessories	34
- Flexible Sensors Cables	35
• Contact Probes	35
• Threaded Sensors	35
- Threaded Sensors Accessories	37
• Accelerometer Sensors	38
• COMMONSense Sensors	39
- COMMONSense Accessories	40
• Parabolic Sensors	41
• Transmitters	36
- Transmitters Accessories	42
• Cables	42
• Headphones	43
• Batteries	44
• Battery Chargers	46
• TankTest Sensors	47
- TankTest Accessories	48
- TankTest Accessories Spareparts	52
• Remote Monitoring Box	53
- Remote Monitoring Box Cables	54
• Cases	55
• Other Accessories	56
• RAPSodyBox	57
- RAPSodyBox Cables	57
• Demo Benches	57

Trainings	59
-----------	----

SDT340 Kit

FS.R340.EU-01



SDT340 DEVICE SET - SDT INT - EU

Consists of:

DMSDTUSB	USER'S MANUAL AND APPLICATION SOFT FOR SDT DEVICES ON USB KEY
FAHOLSAC-01	SHOULDER STRAP W/ LOGO SDT
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FARPMNLABEL	REFLECTIVE LABEL FOR RPM (PACK OF 4 PCS)
FASFTWUASLI00	UAS Lite (FREE OF CHARGE)
FU.R340.001-01	R340 DEVICE Iss.03 W/O BATTERY PACK (S/N 284 YY NNNN)
FU.R340.BDS-02	R340 BATTERY PACK DOCKING STATION
FU.R340.BPS-02	R340 BATTERY PACK STANDARD - 4,8V 3600mAh NiMh
FU.R340.PS1-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - EU
FUCABLSPLE7LE7-10	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SA.R340.CBX.001-01	R340 CARDBOARD PACKING BOX W/ FOAM
SICABUSB-12-01	USB 3.1 CABLE USB C MALE <> USB A MALE 1,00m

FS.R340.UK-01



SDT340 DEVICE SET - SDT INT - UK

Consists of:

DMSDTUSB	USER'S MANUAL AND APPLICATION SOFT FOR SDT DEVICES ON USB KEY
FAHOLSAC-01	SHOULDER STRAP W/ LOGO SDT
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FARPMNLABEL	REFLECTIVE LABEL FOR RPM (PACK OF 4 PCS)
FU.R340.001-01	R340 DEVICE Iss.03 W/O BATTERY PACK (S/N 284 YY NNNN)
FU.R340.BDS-02	R340 BATTERY PACK DOCKING STATION
FU.R340.BPS-02	R340 BATTERY PACK STANDARD - 4,8V 3600mAh NiMh
FU.R340.PS3-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - UK
FUCABLSPLE7LE7-10	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SA.R340.CBX.001-01	R340 CARDBOARD PACKING BOX W/ FOAM
SICABUSB-12-01	USB 3.1 CABLE USB C MALE <> USB A MALE 1,00m

FS.R340.US-01



SDT340 DEVICE SET - SDT INT - US

Consists of:

DMSDTUSB	USER'S MANUAL AND APPLICATION SOFT FOR SDT DEVICES ON USB KEY
FAHOLSAC-01	SHOULDER STRAP W/ LOGO SDT
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FARPMNLABEL	REFLECTIVE LABEL FOR RPM (PACK OF 4 PCS)
FU.R340.001-01	R340 DEVICE Iss.03 W/O BATTERY PACK (S/N 284 YY NNNN)
FU.R340.BDS-02	R340 BATTERY PACK DOCKING STATION
FU.R340.BPS-02	R340 BATTERY PACK STANDARD - 4,8V 3600mAh NiMh
FU.R340.PS2-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - US
FUCABLSPLE7LE7-10	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SA.R340.CBX.001-01	R340 CARDBOARD PACKING BOX W/ FOAM
SICABUSB-12-01	USB 3.1 CABLE USB C MALE <> USB A MALE 1,00m

SDT340 TankTest

FS.R340.MTT-01



FASFTWTTRO1
 FS.FLX2.R16.001-03
 FS.MTT.ACC2-01
 FS.R340.EU-01
 FU.MTT.ACC1.012-01
 FU.R340.BPS-02
 FU.R340.HST.001-01
 FU.R340.TBX.001-1
 FU.TTSY.TTS2.013-01
 FUPUMPVACSA
 FUTTACSETRUBS
 FUTTPICONTUB2
 FUTTPIRUBI5
 FUTTPIRUBO5

SDT340 DEVICE SET - MTT APPLICATION - EU

Consists of:

Tanktest Reporter - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
 FLEXID2 - FLEX AIRBONE SENSOR W/ REMOVABLE SENSOR 16mm (W/O CABLE, L=550mm)
 SDT340 DEVICE SET - SDT INT - EU
 MTT - LEAK SIMULATOR - DIGITAL MANOMETER W/ QUICK COUPLING (ACCESSORY)
 R340 BATTERY PACK STANDARD - 4,8V 3600mAh NiMh
 R340 DEVICE PROTECTION HOLSTER
 TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340
 CAMLOCK 2" W/ 2x SENSOR R340 TTS2 TANK TEST - LEMO7PM (RED/ BLACK), L= 50dm - VITON
 TANK TEST PUMP NON Ex-PROOF
 TANKTEST - RUBBER STOPPER SET
 TANK CONNECTION TUBE 2" - 50cm (KA2" M - G2" F W/ NIPPLE 2" & O-RING 48 x 6)
 RUBBER PIPE Ex-PROOF 1" TANK TO PUMP L=5m W/O FLAME BUSTER (2x CAMLOCK 1" FEMALE - INPUT)
 RUBBER PIPE Ex-PROOF 1" PUMP EXHAUST L=5m W/ FLAME BUSTER (2x CAMLOCK 1" FEMALE- OUTPUT)

SDT270 Kit

FS.R270.DUTRA.EU-02



FAR270BACC-00
 FAUPGRKEY270-SDTI-1
 FU.R340.TBX.001-1
 FUBATTR270
 FUHDPH-21
 FUPWSPUN-01
 FUR270SB

KIT SDT270 w/ key DU>TRA - EU (NEW TOOLCASE)

Consists of:

SDT270 - STANDARD ACCESSORY PACK - SDT INT - EU
 SDT270 STANDAARD - UPGRADE KEY PACK DU>TRA (NEW BASIC SET 2021)
 TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340
 BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly
 HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
 UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)
 SDT270 RECEIVER W/ BLUE RUBBER PROTECTION, W/O BATTERY, BASIC SOFT SB (W/ INTEGRATED S/N)

FS.R270.DUTRA.UK-02



FAR270BACC-03
 FAUPGRKEY270-SDTI-1
 FU.R340.TBX.001-1
 FUBATTR270
 FUHDPH-21
 FUPWSPUN-01
 FUR270SB

KIT SDT270 w/ key DU>TRA - UK (NEW TOOLCASE)

Consists of:

SDT270 - STANDARD ACCESSORY PACK - SDT INT - UK
 SDT270 STANDAARD - UPGRADE KEY PACK DU>TRA (NEW BASIC SET 2021)
 TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340
 BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly
 HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
 UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)
 SDT270 RECEIVER W/ BLUE RUBBER PROTECTION, W/O BATTERY, BASIC SOFT SB (W/ INTEGRATED S/N)

Part number	Description
FS.R270.DUTRA.US-02	KIT SDT270 w/ key DU>TRA - US (NEW TOOLCASE)
 FAR270BACC-02 FAUPGRKEY270-SDTI-1 FU.R340.TBX.001-1 FUBATTR270 FUHDPH-21 FUPWSPUN-01 FUR270SB	Consists of: SDT270 - STANDARD ACCESSORY PACK - SDT INT - US SDT270 STANDAARD - UPGRADE KEY PACK DU>TRA (NEW BASIC SET 2021) TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340 BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx) SDT270 RECEIVER W/ BLUE RUBBER PROTECTION, W/O BATTERY, BASIC SOFT SB (W/ INTEGRATED S/N)

SDT270 Keys and Upgrades

FA.UKIT.R270.K1K2	UPGRADE R270 MK1 > R270 MK2 (INCLUDING UPLOAD EXISTING KEYS MK1 + CALIBRATION)
 AC.R270 FUBATTR270 FUR270SB	Consists of: CALIBRATION & VERIFICATION SDT270 (BASIC KIT) W/ CERTIFICATE BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly SDT270 RECEIVER W/ BLUE RUBBER PROTECTION, W/O BATTERY, BASIC SOFT SB (W/ INTEGRATED S/N)

FA.UKIT.R270.LBX-02	UPGRADE R270 MK2 WITH LUBExpert KEY (INCLUDING HARDWARE)
 DMSDTUSB FAUPGRKEY270L FU.LBX.DVC.001-01 FU.SEAC.LUB.006-01 FU.SEN.LUBE.001-01 FUCABLSPILE7LE7-10 FUSEACMAG-01 FUSEACMAG-02	Consists of: USER'S MANUAL AND APPLICATION SOFT FOR SDT DEVICES ON USB KEY SDT270 ACTIVATION KEY - LUBE (ONLY FOR FUR270 MK2 SU/DU) LUBExpert - DEVICE CRADLE LUBE ADAPTER w/ G-COUPLER (M6 - BSP 1/8") LUBESens1 w/o CABLE CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2 FLAT MAGNETIC FOOT D25x14 M6 CURVED MAGNETIC FOOT D30x23 M6

FAUPGRKEY270A-SDTI-1	SDT270 ATEX - UPGRADE KEY PACK DU>TR (NEW BASIC SET 2021)
 FAUPGRKEY270DU FAUPGRKEY270R FAUPGRKEY270T	Consists of: SDT270 DU UPGRADE KEY - DYNAMIC DOWNLOAD & UPLOAD FROM UAS SDT270 ACTIVATION KEY - BUILT-IN RPM SENSOR SDT270 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR

FAUPGRKEY270DU	SDT270 DU UPGRADE KEY - DYNAMIC DOWNLOAD & UPLOAD FROM UAS
	

Part number	Description
FAUPGRKEY270DU-DW	SDT270 DU TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
	
FAUPGRKEY270DW	SDT270 DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
	
FAUPGRKEY270L	SDT270 ACTIVATION KEY - LUBE (ONLY FOR FUR270 MK2 SU/DU)
	
FAUPGRKEY270-SDTI-1	SDT270 STANDAARD - UPGRADE KEY PACK DU>TRA (NEW BASIC SET 2021)
	
FAUPGRKEY270A	SDT270 ACTIVATION KEY - ICP POWER SUPPLY (ACCELEROMETRY)
FAUPGRKEY270DU	SDT270 DU UPGRADE KEY - DYNAMIC DOWNLOAD & UPLOAD FROM UAS
FAUPGRKEY270R	SDT270 ACTIVATION KEY - BUILT-IN RPM SENSOR
FAUPGRKEY270T	SDT270 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR
SDT200 Kit	
FSR200SD-01	KIT SDT200 SD (BASIC - NEW TOOLCASE)
	
FAR200BACC-00	SDT200 - STANDARD ACCESSORY PACK - SDT EU
FASFTWDD01	DATA DUMP - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION (DELIVERED WITH SDT200SD)
FU.R340.TBX.001-1	TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340
FUBATTR270	BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUPWSPUN-01	UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)
FUR200SD	SDT200 RECEIVER W/ RUBBER CURB RING & W/O BATTERY

Part number**Description****LUBExpert****FS.LBX.001-02****LUBExpert Kit - W/ Temperature Key, New Lube Adaptor - US/EU**

FA.LBX.ACCP.001

FAUPGRKEY200T

FU.LBX.001

FU.LBX.CBOX.001-01

FU.LBX.DVC.001-01

FU.SEAC.LUB.006-01

FU.SEN.LUBE.001-01

FUBATTR270

FUCABLSPLE7LE7-10

FUHDPH-21

FUPWSPUN-01

FUSEACMAG-01

FUSEACMAG-02

Consists of:

LUBExpert - STANDARD ACCESSORY PACK (US/EU)

SDT200 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR

SDT LUBExpert w/o BATTERY

LUBExpert - BLUE SUITECASE - YELLOW LOCKS (w/ logo SDT + Foam)

LUBExpert - DEVICE CRADLE

LUBE ADAPTER w/ G-COUPLER (M6 - BSP 1/8")

LUBESens1 w/o CABLE

BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBESense1, FLX2

HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND

UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)

FLAT MAGNETIC FOOT D25x14 M6

CURVED MAGNETIC FOOT D30x23 M6

FS.LBX.002-02**LUBExpert Kit - W/ Temperature Key, New Lube Adaptor - EU**

FA.LBX.ACCP.002

FAUPGRKEY200T

FU.LBX.001

FU.LBX.CBOX.001-01

FU.LBX.DVC.001-01

FU.SEAC.LUB.006-01

FU.SEN.LUBE.001-01

FUBATTR270

FUCABLSPLE7LE7-10

FUHDPH-21

FUPWSPUN-01

FUSEACMAG-01

FUSEACMAG-02

Consists of:

LUBExpert - STANDARD ACCESSORY PACK EU

SDT200 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR

SDT LUBExpert w/o BATTERY

LUBExpert - BLUE SUITECASE - YELLOW LOCKS (w/ logo SDT + Foam)

LUBExpert - DEVICE CRADLE

LUBE ADAPTER w/ G-COUPLER (M6 - BSP 1/8")

LUBESens1 w/o CABLE

BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBESense1, FLX2

HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND

UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)

FLAT MAGNETIC FOOT D25x14 M6

CURVED MAGNETIC FOOT D30x23 M6

FS.LBX.003-02**LUBExpert Kit - W/ Temperature Key, New Lube Adaptor - UK**

FA.LBX.ACCP.003

FAUPGRKEY200T

FU.LBX.001

FU.LBX.CBOX.001-01

FU.LBX.DVC.001-01

FU.SEAC.LUB.006-01

FU.SEN.LUBE.001-01

FUBATTR270

FUCABLSPLE7LE7-10

FUHDPH-21

FUPWSPUN-01

FUSEACMAG-01

FUSEACMAG-02

Consists of:

LUBExpert - STANDARD ACCESSORY PACK UK

SDT200 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR

SDT LUBExpert w/o BATTERY

LUBExpert - BLUE SUITECASE - YELLOW LOCKS (w/ logo SDT + Foam)

LUBExpert - DEVICE CRADLE

LUBE ADAPTER w/ G-COUPLER (M6 - BSP 1/8")

LUBESens1 w/o CABLE

BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBESense1, FLX2

HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND

UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)

FLAT MAGNETIC FOOT D25x14 M6

CURVED MAGNETIC FOOT D30x23 M6

LUBExpert Key

FAUPGRKEYLBXD

UPGRADE KEY CODE LBX D - LUBExpert Option DYNAMIC



LUBExpert ON-GUARD

FS.SRL.000-01

SRL - ON-GUARD SYSTEM STANDARD KIT w/ SENSORS & ACCESSORIES (NO ENCLOSURE)



Consists of:

FU.RSC.CABL.01.100-1
FU.SEN.RSC.101-03
FU.SRL.PLC.000-01
SIMSENSCP2MP-01-C

SENSOR-/ACTOR CABLE M8 4PF <> FREE END 10,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
COMMONSense; RSC US STAT 4-20mA M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 573 YY XXXX)
SRL - ON-GUARD SYSTEM - PLC SYSTEM W/ SOFTWARE
MOUNTING PAD CP2

FS.SRL.001-01

SRL - ON-GUARD SYSTEM WITH COATED STEEL ENCLOSURE 400x300x155



Consists of:

FU.RSC.CABL.01.100-1
FU.SEN.RSC.101-03
FU.SRL.ENC.001-01
FU.SRL.PLC.000-01
SIMSENSCP2MP-01-C

SENSOR-/ACTOR CABLE M8 4PF <> FREE END 10,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
COMMONSense; RSC US STAT 4-20mA M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 573 YY XXXX)
SRL - ON-GUARD COATED STEEL ENCLOSURE 400x300x155
SRL - ON-GUARD SYSTEM - PLC SYSTEM W/ SOFTWARE
MOUNTING PAD CP2

FS.SRL.DUM.001-02

SRL - ON-GUARD - MOBILE UNIT 4 CHANNEL W/ TOOLCASE



Consists of:

FA.VIG.NTW.001-01
FA.VIG.NTW.001-02
FU.RSC.CABL.05.100-1
FU.SEN.RSC.101-03
FU.SRL.CABL.05.100-1
FU.SRL.CBOX.001-02
SI.LBX.PRT.004
SI.PLC.SFTW.001-01
SI.PLC.UNIPI.001
SIMSENSCP2MP-01-C

INDUSTRIAL 4G/LTE (Cat 4), 3G, 2G ROUTER
INDUSTRIAL 4G/LTE (Cat 4), 3G, 2G ROUTER (GLOBAL)
SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 10,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
COMMONSense; RSC US STAT 4-20mA M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 573 YY XXXX)
SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 10,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
SRL - MOBIL UNIT TOOLCASE (4 CHANNEL WIRED)
PERMA STAR CONTROL 2.0 - DRIVE UNIT AUTOMATIC LUBRICATION (PERMA TEC 108985)
SRL - ON-GUARD SYSTEM - PLC SYSTEM SOFTWARE (μSDHC)
SRL - ON-GUARD SYSTEM - PLC SYSTEM - REVOLUTION PI - 12 DI/4 DO - 10 RO - 9 AI/ 9 AO - 1 RS485
MOUNTING PAD CP2

Checkers Range

FS.HTC.001-03



HATChecker KIT

Consists of:

FA.FLX2.HND.003-01
FA.FLX2.R10.001-01
FA.TSO9.DVP
FA.TSO9.MMF.005-01
FAHOLSAC-01
FU.FLX2.001-03
FU.HTC.001-01
FU.HTC.CBOX.001-01
FU.HTC.UGD.001-01
FU.TSO9.001-03
FU.TSO9.002-02
FUCABLSPLE7LE7-10
FUHDPH-21
FUTOOLSCRDRIV
SIBAT1,5VALK-AA
SICABUSBAUSBBM

FLEX2 - HANDLE 400mm W/ RUBBER
REMOVABLE SENSOR 10mm FOR FLX2
TSO9 - DEVICE PROTECTION EPDM BLACK W/ MAGNETICS
TSO1/TSO9 - ATTENUATION TOOL FUNCTIONAL TEST
SHOULDER STRAP W/ LOGO SDT
FlexID2 - FLEXIBLE AIRBONE SENSOR 400mm W/O SENSOR
HATChecker W/O BATTERIES
HATChecker - BLUE SUITECASE - BLACK LOCKS (w/ logo SDT + Foam)
HATChecker - USER'S GUIDE W/ DATASHEET
T-Sonic9 - US EMITTER DEVICE w/o BATTERIES
T-Sonic9 - REMOTE CONTROL w/ BATTERIE
CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
BATTERY ALKALINE 1,5V AA
CABLE USB TYPE A - B5 MINI

FS.LBC.001-01



LUBEChecker KIT

Consists of:

FU.LBC.001-01
FU.LBC.CBOX.001-01
FU.LBC.DVC.001-02
FU.LBC.DVC.002-01
FU.LBC.UGD.001-01
FU.SEN.LUBE.001-01
FUCABLSPLE7LE7-10
FUHDPH-21
FUSEACLUBE-03-A
FUSEACMAG-01
FUSEACMAG-02
FUTOOLSCRDRIV
SIBAT1,5VALK-AA
SICABUSBAUSBBM

LUBEChecker W/O BATTERIES
LUBEChecker - BLUE SUITECASE - YELLOW LOCKS (w/ logo SDT + Foam)
LUBEChecker- DEVICE CRADLE W/ HOOK & LOOP STRAP
LUBEChecker- DEVICE CRADLE MAGNETIC
LUBEChecker - USER'S GUIDE W/ DATASHEET
LUBESens1 w/o CABLE
CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
LUBE ADAPTER FOR USE W/ FUSCRS3-01 (M6 - BSP 1/8")
FLAT MAGNETIC FOOT D25x14 M6
CURVED MAGNETIC FOOT D30x23 M6
SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
BATTERY ALKALINE 1,5V AA
CABLE USB TYPE A - B5 MINI

FS.LKC.001-01



LEAKChecker KIT

Consists of:

FA.FLX2.R10.001-01
FA.FLX2.R16.001-01
FU.LKC.001-01
FU.LKC.CBOX.001-01
FU.LKC.UGD.001-01
FUHDPH-21
FUTOOLSCRDRIV
SIBAT1,5VALK-AA
SICABUSBAUSBBM
SIRUBSENS18MMSI

REMOVABLE SENSOR 10mm FOR FLX2
REMOVABLE SENSOR 16mm FOR FLX2
LEAKChecker W/O SENSOR, W/O BATTERIES
LEAKChecker - BLUE SUITECASE - GREEN LOCKS (w/ logo SDT + Foam)
LEAKChecker - USER'S GUIDE W/ DATASHEET
HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
BATTERY ALKALINE 1,5V AA
CABLE USB TYPE A - B5 MINI
RUBBER FOR SENSOR Ø18mm

Part number**Description****FS.TIC.001-01****TIGHTChecker SV KIT****Consists of:**

FA.FLX2.R10.001-01

REMOVABLE SENSOR 10mm FOR FLX2

FA.FLX2.R16.001-01

REMOVABLE SENSOR 16mm FOR FLX2

FU.FLX2.001-01

FlexID2 - FLEXIBLE AIRBONE SENSOR W/O SENSOR (550mm)

FU.TIC.001-01

TIGHTChecker W/O BATTERIES

FU.TIC.CBOX.001-01

TIGHTChecker - BLUE SUITECASE - RED LOCKS (w/ logo SDT + Foam)

FU.TIC.UGD.001-01

TIGHTChecker - USER'S GUIDE W/ DATASHEET

FU.TSO1.001

T-Sonic1 - US EMITTER DEVICE w/o BATTERIES

FUCABLSPLE7LE7-10

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2

FUHDPH-1

HEADPHONE SET SDT BLUE NECK

FUTOOLSCRDRIV

SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)

SIBAT1,5VALK-AA

BATTERY ALKALINE 1,5V AA

SICABUSBAUSBBM

CABLE USB TYPE A - B5 MINI

SIRUBSENS18MMSI

RUBBER FOR SENSOR Ø18mm

FS.TPC.001-01**TRAPChecker KIT****Consists of:**

FU.SEN.RS2N.001-01

RS2NL100 NEEDLE CONTACT PROBE W/O CABLE (NL=82mm)

FU.TPC.001-01

TRAPChecker W/O BATTERIES

FU.TPC.CBOX.001-01

TRAPChecker - BLUE SUITECASE - BLUE LOCKS (w/ logo SDT + Foam)

FU.TPC.UGD.001-01

TRAPChecker - USER'S GUIDE W/ DATASHEET

FUCABLSPLE7LE7-10

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2

FUHDPH-21

HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND

FUTOOLSCRDRIV

SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)

SIBAT1,5VALK-AA

BATTERY ALKALINE 1,5V AA

SICABUSBAUSBBM

CABLE USB TYPE A - B5 MINI

FS.ULC.002-01**ULTRAChecker KIT****Consists of:**

FU.SEN.RS2T.001-01

RS2T THREADED SENSOR W/O CABLE

FU.SEN.UTS.001-01

ULTRASense US SENSOR

FU.ULC.001-01

ULTRAChecker W/O BATTERIES

FU.ULC.CBOX.001-01

ULTRAChecker - BLUE SUITECASE - GREY LOCKS (w/ logo SDT + Foam)

FU.ULC.UGD.001-01

ULTRAChecker - USER'S GUIDE W/ DATASHEET

FUCABLSPLE7LE7-10

CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2

FUHDPH-21

HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND

FUSEACMAG-02

CURVED MAGNETIC FOOT D30x23 M6

FUTOOLSCRDRIV

SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)

SA.CP2.MMF.002-B

NEEDLE ASSEMBLY 133MM CP2 (FOR USE W/ SISENSAMHS130)

SIBAT1,5VALK-AA

BATTERY ALKALINE 1,5V AA

SICABUSBAUSBBM

CABLE USB TYPE A - B5 MINI

Part number	Description
FU.HTC.001-01	HATCHecker W/O BATTERIES
	
ABPRODTIME	LABOUR COST - (min) (1)
FA.CHK.LCD.001-01	CHECKER - DISPLAY ASSEMBLY
FA.CHK.LE7.001-01	CHECKER - LE7 CONNECTOR ASSEMBLY FOR EXTERNAL SENSOR
FA.CHK.PCB.001-01	CHECKER - MAIN BOARD
FA.HTC.CASE.001-01	HATCHECKER - CASE (w/o engraving, w/ LABEL HATChecker w/ screws)

Checkers Accessories

FS.LBC.DVC.000-01	LUBEChecker - DEVICE CRADLE SET
	
	Consists of:
FU.LBC.DVC.001-02	LUBEChecker- DEVICE CRADLE W/ HOOK & LOOP STRAP
FU.LBC.DVC.002-01	LUBEChecker- DEVICE CRADLE MAGNETIC

Online4US

FS.O4US.EU.001-02	O4US MK2 Iss.03 - EXTENSION UNIT - COATED STEEL ENCLOSURE
	
	Consists of:
FU.O4US.BEM.002	O4US MK2 - BUS EXPANSION MODULE Iss.03 (BUS TERMINATION) (S/N 603 YY XXXX)
FU.O4US.ENC.003	O4US MK2 - EXTENSION UNIT STEEL COATED ENCLOSURE 500x400x210 W/ BASE WIRING

FS.O4US.EU.002-02	O4US MK2 Iss.03 - EXTENSION UNIT - STAINLESS STEEL ENCLOSURE
	
	Consists of:
FU.O4US.BEM.002	O4US MK2 - BUS EXPANSION MODULE Iss.03 (BUS TERMINATION) (S/N 603 YY XXXX)
FU.O4US.ENC.004	O4US MK2 - EXTENSION UNIT STAINLESS STEEL ENCLOSURE 500x400x210 W/ BASE WIRING

FS.O4US.MU.001-02	O4US MK2 Iss.03 - MAIN UNIT W/ DISPLAY - COATED STEEL ENCLOSURE
	
	Consists of:
FU.O4US.BEM.002	O4US MK2 - BUS EXPANSION MODULE Iss.03 (BUS TERMINATION) (S/N 603 YY XXXX)
FU.O4US.CUM.002	O4US MK2 - CENTRAL UNIT MODULE Iss.03 (W/ RAIL BUS)
FU.O4US.ENC.001	O4US MK2 - MAIN UNIT STEEL COATED ENCLOSURE 500x400x210 W/ BASE WIRING
FU.O4US.LCD.002	O4US MK2 - LCD DISPLAY Iss.03 W/ FRAME & COVER
FU.O4US.PSU.001	O4US MK2 - POWER SUPPLY UNIT 24V 60W DIN-RAIL MOUNT

Part number	Description
FS.O4US.MU.002-02	O4US MK2 Iss.03 - MAIN UNIT W/ DISPLAY - STAINLESS STEEL ENCLOSURE
 FU.O4US.BEM.002 FU.O4US.CUM.002 FU.O4US.ENC.002 FU.O4US.LCD.002 FU.O4US.PSU.001	Consists of: O4US MK2 - BUS EXPANSION MODULE Iss.03 (BUS TERMINATION) (S/N 603 YY XXXX) O4US MK2 - CENTRAL UNIT MODULE Iss.03 (W/ RAIL BUS) O4US MK2 - MAIN UNIT STAINLESS STEEL ENCLOSURE 500x400x210 W/ BASE WIRING O4US MK2 - LCD DISPLAY Iss.03 W/ FRAME & COVER O4US MK2 - POWER SUPPLY UNIT 24V 60W DIN-RAIL MOUNT
FU.O4US.ACC.002	ANYBUS COMMUNICATOR ETHERNET/IP 2-PORT
	
FU.O4US.BEM.002	O4US MK2 - BUS EXPANSION MODULE Iss.03 (BUS TERMINATION) (S/N 603 YY XXXX)
	
FU.O4US.CUM.003	O4US MK2 - CENTRAL UNIT MODULE Iss.04 (W/ RAIL BUS)
	
FU.O4US.DIM.002	O4US MK2 - DIGITAL INPUT MODULE Iss.03 (W/ RAIL BUS)
	
FU.O4US.DOM.002	O4US MK2 - DIGITAL OUTPUT MODULE Iss.03 (W/ RAIL BUS)
	
FU.O4US.ENC.001	O4US MK2 - MAIN UNIT STEEL COATED ENCLOSURE 500x400x210 W/ BASE WIRING
	

Part number	Description
FU.O4US.ENC.002 	O4US MK2 - MAIN UNIT STAINLESS STEEL ENCLOSURE 500x400x210 W/ BASE WIRING
FU.O4US.ENC.003 	O4US MK2 - EXTENSION UNIT STEEL COATED ENCLOSURE 500x400x210 W/ BASE WIRING
FU.O4US.ENC.004 	O4US MK2 - EXTENSION UNIT STAINLESS STEEL ENCLOSURE 500x400x210 W/ BASE WIRING
FU.O4US.LCD.002 	O4US MK2 - LCD DISPLAY Iss.03 W/ FRAME & COVER
FU.O4US.PSU.001 	O4US MK2 - POWER SUPPLY UNIT 24V 60W DIN-RAIL MOUNT
FU.O4US.PSU.002 	O4US MK2 - POWER SUPPLY UNIT 24V 30W DIN-RAIL MOUNT
FU.O4US.SH1.002-02 	O4US MK2 Iss.03 - US SENSOR HOLDER W/ CABLE (5,1..10m) - WRTBL3663-5P
FU.O4US.SH1.003-02 	O4US MK2 Iss.03 - US SENSOR HOLDER W/ CABLE (10,1..25m) - WRTBL3663-5P

Part number	Description
FU.O4US.SH1.004-02	O4US MK2 Iss.03 - US SENSOR HOLDER W/ CABLE (25,1..35m) - WRTBL3663-5P
	
FU.O4US.SH1.005-02	O4US MK2 Iss.03 - US SENSOR HOLDER W/ CABLE (35,1..50m) - WRTBL3663-5P
	
FU.O4US.USM.001-03	O4US MK2 - US SENSOR MODULE Iss.04 (W/ RAIL BUS)
	
FU.O4US.VIB.001-02	O4US MK2 - VIB SENSOR MODULE Iss.03 (W/ RAIL BUS)
	
Online4US Sensors	
FU.O4US.SH1.001-02	O4US MK2 Iss.03 - US SENSOR HOLDER W/ CABLE (<5m) - WRTBL3663-5P
	
FU.SEN.RC25.001-01	O4US MK2 - US SENSOR 25mm CLOSED (W/ PRE-AMPLIFIER)
	
FU.SEN.RO16.001-01	O4US MK2 - US SENSOR 16mm OPEN (W/ PRE-AMPLIFIER)
	

Online4US Sensors Cables

FU.O4US.CABL.001-02

O4US MK2 Iss.03 - RS2T CABLE (<5m) - CABLE FOR FUSCRS4-01:
LE7M<>WRTBL3663-5P



FU.O4US.CABL.002-02

O4US MK2 Iss.03 - RS2T CABLE (5,1..10m) - CABLE FOR FUSCRS4-01:
LE7M<>WRTBL3663-5P



FU.O4US.CABL.003-02

O4US MK2 Iss.03 - RS2T CABLE (10,1..25m) - CABLE FOR FUSCRS4-01:
LE7M<>WRTBL3663-5P



FU.O4US.CABL.004-02

O4US MK2 Iss.03 - RS2T CABLE (25,1..35m) - CABLE FOR FU.SEN.RS2T:
LE7M<>WRTBL3663-5P



FU.O4US.CABL.005-02

O4US MK2 Iss.03 - RS2T CABLE (35,1..50m) - CABLE FOR FUSCRS4-01:
LE7M<>WRTBL3663-5P



FU.O4US.CABL.011-01

O4US MK2 Iss.03 - CABLE (<5m) FOR RS2 IP65, LUBEsense1 IP65: LE7M
IP65<>WRTBL3663-5P



FU.O4US.CABL.012-01

O4US MK2 Iss.03 - CABLE (5,1..10m) FOR RS2 IP65, LUBEsense1 IP65:
LE7M IP65<>WRTBL3663-5P



Part number	Description
FU.O4US.CABL.013-01	O4US MK2 Iss.03 - CABLE (10,1..25m) FOR RS2 IP65, LUBEsense1 IP65: LE7M IP65<>WRTBL3663-5P
	
FU.O4US.CABL.014-01	O4US MK2 Iss.03 - CABLE (25,1..35m) FOR RS2 IP65, LUBEsense1 IP65: LE7M IP65<>WRTBL3663-5P
	
FU.O4US.CABL.015-01	O4US MK2 Iss.03 - CABLE (35,1..50m) FOR RS2 IP65, LUBEsense1 IP65: LE7M IP65<>WRTBL3663-5P
	
FU.O4US.CABL.101-02	O4US MK2 Iss.03 - ACCELERO HS100 CABLE (<5m) - CABLE FOR FU.SENS.ACC.001: 2 PIN MS CON<>WRTBL3663-5P
	
FU.O4US.CABL.102-02	O4US MK2 Iss.03 - ACCELERO HS100 CABLE (5,1..10m) - CABLE FOR FU.SENS.ACC.001: 2 PIN MS CON<>WRTBL36
	
FU.O4US.CABL.103-02	O4US MK2 Iss.03 - ACCELERO HS100 CABLE (10,1..25m) - CABLE FOR FU.SENS.ACC.001: 2 PIN MS CON<>WRTBL3
	
FU.O4US.CABL.104-02	O4US MK2 Iss.03 - ACCELERO HS100 CABLE (25,1..35m) - CABLE FOR FU.SENS.ACC.001: 2 PIN MS CON<>WRTBL3
	
FU.O4US.CABL.105-02	O4US MK2 Iss.03 - ACCELERO HS100 CABLE (35,1..50m) - CABLE FOR FU.SENS.ACC.001: 2 PIN MS CON<>WRTBL3
	

Part number	Description
FU.O4US.CABL.201-01	O4US MK2 - BUS EXTENSION CABLE (MAIN UNIT <> EXTENSION UNIT)
	

CRYSOUND

FS.SVU.PRO.100-01



CRYSOUND 2620 - PRO KIT (W/ LEAKChecker) - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP

Consists of:

FA.FLX2.R16.001-01	REMOVABLE SENSOR 16mm FOR FLX2
FU.LKC.001-01	LEAKChecker W/O SENSOR, W/O BATTERIES
FU.LKC.UGD.001-01	LEAKChecker - USER'S GUIDE W/ DATASHEET
FU.SVU.100-01	CRYSOUND 2620 - ACOUSTIC IMAGING CAMERA - 64 channel MEMS 2÷40kHz
FU.SVU.10X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - HAND STRAP
FU.SVU.10X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA - SHOULDER STRAP
FU.SVU.10X.AD01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB ADAPTER MEMORY CARD
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.10X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB 3.0 C POWER CABLE
FU.SVU.10X.HDPH01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - EARPHONE/ EARBUDS
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SIBAT1,5VAA	BATTERY ALKALINE 1,5V AA
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

FS.SVU.PRO.101-01



CRYSOUND 2623 - PRO KIT (W/ LEAKChecker) - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP

Consists of:

FA.FLX2.R16.001-01	REMOVABLE SENSOR 16mm FOR FLX2
FU.LKC.001-01	LEAKChecker W/O SENSOR, W/O BATTERIES
FU.LKC.UGD.001-01	LEAKChecker - USER'S GUIDE W/ DATASHEET
FU.SVU.101-01	CRYSOUND 2623 - ACOUSTIC IMAGING CAMERA 128 channel MEMS 2÷40kHz
FU.SVU.10X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - HAND STRAP
FU.SVU.10X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA - SHOULDER STRAP
FU.SVU.10X.AD01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB ADAPTER MEMORY CARD
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.10X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB 3.0 C POWER CABLE
FU.SVU.10X.HDPH01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - EARPHONE/ EARBUDS
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SIBAT1,5VAA	BATTERY ALKALINE 1,5V AA
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

Part number	Description
FS.SVU.PRO.110-01	CRYSOUND 8124 - PRO KIT (W/ LEAKChecker) - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FA.FLX2.R16.001-01	REMOVABLE SENSOR 16mm FOR FLX2
FU.LKC.001-01	LEAKChecker W/O SENSOR, W/O BATTERIES
FU.LKC.UGD.001-01	LEAKChecker - USER'S GUIDE W/ DATASHEET
FU.SVU.110-01	CRYSOUND 8124 - ACOUSTIC IMAGING CAMERA 200 channel MEMS 2÷100kHz
FU.SVU.11X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - HAND STRAP
FU.SVU.11X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - SHOULDER STRAP
FU.SVU.11X.BP01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY PACK
FU.SVU.11X.BPDS01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY CHARGER for 1 PACK (IA2101)
FU.SVU.11X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - POWER CABLE for loader><power supply
FU.SVU.11X.PS02-01	
FU.SVU.TBX.002-1	CRYSOUND ACOUSTIC IMAGING CAMERA SERIE 81** - TOOLBOX W/ INLAY & DOC HOLDER
FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm
FS.SVU.STN.100-01	CRYSOUND 2620 - BASIC KIT - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FU.SVU.100-01	CRYSOUND 2620 - ACOUSTIC IMAGING CAMERA - 64 channel MEMS 2÷40kHz
FU.SVU.10X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - HAND STRAP
FU.SVU.10X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA - SHOULDER STRAP
FU.SVU.10X.AD01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB ADAPTER MEMORY CARD
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.10X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB 3.0 C POWER CABLE
FU.SVU.10X.HDPH01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - EARPHONE/ EARBUDS
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER
FS.SVU.STN.101-01	CRYSOUND 2623 - BASIC KIT - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FU.SVU.101-01	CRYSOUND 2623 - ACOUSTIC IMAGING CAMERA 128 channel MEMS 2÷40kHz
FU.SVU.10X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - HAND STRAP
FU.SVU.10X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA - SHOULDER STRAP
FU.SVU.10X.AD01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB ADAPTER MEMORY CARD
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.10X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB 3.0 C POWER CABLE
FU.SVU.10X.HDPH01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - EARPHONE/ EARBUDS
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER

Part number	Description
FS.SVU.STN.102-01	CRYSOUND 2624 - BASIC KIT - ATEX ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FU.SVU.102-01	CRYSOUND 2624 - ACOUSTIC IMAGING CAMERA ATEX 128 channel MEMS 2÷40kHz
FU.SVU.10X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - HAND STRAP
FU.SVU.10X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA - SHOULDER STRAP
FU.SVU.10X.AD01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB ADAPTER MEMORY CARD
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.10X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - USB 3.0 C POWER CABLE
FU.SVU.10X.HDPH01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - EARPHONE/ EARBUDS
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER

FS.SVU.STN.110-01	CRYSOUND 8124 - BASIC KIT - ACOUSTIC IMAGING CAMERA W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.110-01	CRYSOUND 8124 - ACOUSTIC IMAGING CAMERA 200 channel MEMS 2÷100kHz
FU.SVU.11X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - HAND STRAP
FU.SVU.11X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - SHOULDER STRAP
FU.SVU.11X.BP01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY PACK
FU.SVU.11X.BPDS01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY CHARGER for 1 PACK (IA2101)
FU.SVU.11X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - POWER CABLE for loader><power supply
FU.SVU.TBX.002-1	CRYSOUND ACOUSTIC IMAGING CAMERA SERIE 81** - TOOLBOX W/ INLAY & DOC HOLDER

FS.SVU.STN.111-01	CRYSOUND 8125 - BASIC KIT - ACOUSTIC IMAGING CAMERA IECEx W/ HAND STRAP AND RUBBER GRIP
	Consists of:
FU.SVU.10X.BPS01-01	CRYSOUND ACOUSTIC IMAGING CAMERA - PWR ADAPTER - BAT LOADER - 100÷240V 50/60Hz 1,3A - USB3.0C OUTPUT
FU.SVU.111-01	CRYSOUND 8125 - ACOUSTIC IMAGING CAMERA IECEx 200 channel MEMS 2÷100kHz
FU.SVU.11X.AC01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - HAND STRAP
FU.SVU.11X.AC02-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - SHOULDER STRAP
FU.SVU.11X.BP01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY PACK
FU.SVU.11X.BPDS01-01	CRYSOUND IMAGING CAMERA serie 8120 - SMART BATTERY CHARGER for 1 PACK (IA2101)
FU.SVU.11X.CBL01-01	CRYSOUND ACOUSTIC IMAGING CAMERA serie 8120 - POWER CABLE for loader><power supply
FU.SVU.TBX.002-1	CRYSOUND ACOUSTIC IMAGING CAMERA SERIE 81** - TOOLBOX W/ INLAY & DOC HOLDER

Vigilant

FS.VIGILANT.001	VIGILANT PERMANENT W/ 8 DYNAMIC + 4 STATIC INPUTS - STANDARD CONFIGURATION
	Consists of:
FA.VGL.CO1-01	VIGILANT - MODBUS MASTER (INCLUDED IN STD CONF)
FA.VGL.CO2-01	VIGILANT - OPC UA CLIENT (INCLUDED IN STD CONF)
FA.VGL.DOD1-01	VIGILANT - SPECTRUM WATERFALL WIDGET (INCLUDED IN STD CONF)
FA.VGL.DOD4-01	VIGILANT - LONG WAVEFORM ANALYSIS (INCLUDED IN STD CONF)
FU.VIGILANT.001-01	VIGILANT W/ 8 DYN. + 4 STAT INP / EXT.PROC.BLCKS / SPECT. & WAVEFORM WIDG./ DEMODULATION

Part number

Description

FS.VIGILANT.002

VIGILANT MOBILITY W/ 8 DYNAMIC + 4 STATIC INPUTS -
STANDARD CONFIGURATION

Consists of:

FA.VGL.COA1-01

VIGILANT - MODBUS MASTER (INCLUDED IN STD CONF)

FA.VGL.COA2-01

VIGILANT - OPC UA CLIENT (INCLUDED IN STD CONF)

FA.VGL.DOD1-01

VIGILANT - SPECTRUM WATERFALL WIDGET (INCLUDED IN STD CONF)

FA.VGL.DOD4-01

VIGILANT - LONG WAVEFORM ANALYSIS (INCLUDED IN STD CONF)

FA.VGL.MC001-01

VIGILANT - MOBILITY CASE including MODEM WIFI/4G & POWER SUPPLY

FU.VIGILANT.001-01

VIGILANT W/ 8 DYN. + 4 STAT INP / EXT.PROC.BLCKS / SPECT. & WAVEFORM WIDG./ DEMODULATION

Vigilant/RSC Cables

FU.ACC.CABL.01.015-1

SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 1,5m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65

FU.ACC.CABL.01.030-1

SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 3,0m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65

FU.ACC.CABL.01.050-1

SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 5,0m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65

FU.ACC.CABL.01.100-1

SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 10,0m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65




FU.ACC.CABL.01.150-1




SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 15,0m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65

FU.ACC.CABL.01.200-1

SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 20,0m -
SHIELDED - PUR RAL7021 - -25°..+90°C IP65

Part number	Description
FU.ACC.CABL.01.300-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END 30,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.01.XXX-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> FREE END xx,xm (0,2...50m) - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.015-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 1,5m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.030-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 3,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.050-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 5,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.100-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 10,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.150-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 15,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.200-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 20,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	

Part number	Description
FU.ACC.CABL.02.300-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM 30,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.02.XXX-2	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM xx, xm (40m) - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.ACC.CABL.03.XXX-1	SENSOR-/ACTOR CABLE MS2 STRAIGHT (ACC) <> M8 4PM xx, xm (0,2...30m) - SHIELDED - EFTE - -65°..+150°C
	
FU.ACC.CABL.04.100-1	ACC SENSOR CABLE MS2 STRAIGHT (ACC) <> FREE END 10,0m - SHIELDED - FEP BLUE -80°..+200°
	
FU.ACC.CABL.04.250-1	ACC SENSOR CABLE MS2 STRAIGHT (ACC) <> FREE END 25,0m - SHIELDED - FEP BLUE -80°..+200°
	
FU.ACC.CABL.05.005-1	SENSOR-/ACTOR FEP CABLE MS3 FEM STRAIGHT (ACC & TEMP) - Length 5m - Free end - -80°...+180°C
	
FU.ACC.CABL.05.020-1	SENSOR-/ACTOR FEP CABLE MS3 FEM STRAIGHT (ACC & TEMP) - Length 20m - Free end - -80°...+180°C
	
FU.ACC.CABL.11.030-1	SAC-4P- 3,0-PUR/M12FS (1668111) - SENSOR-/ACTOR CABLE M12 4PF <> FREE END 3,0m - SHIELDED - PUR BLAC +180°C
	

Part number	Description
FU.ACC.CABL.11.100-1	SAC-4P- 10,0-PUR/M12FS (1683002) - SENSOR-/ACTOR CABLE M12 4PF <> FREE END 10,0m - UNSHIELDED - PUR +180°C
	
FU.ACC.CABL.12.100-1	SAC-4P- 10,0-PUR/M12FS SH (1500716) - SENSOR-/ACTOR CABLE M12 4PF <> FREE END 10,0m - SHIELDED - PUR +180°C
	
FU.ACC.CABL.13.XXX-1	SPECIFIC CABLE TACHO/VIGILANT - M12 4PF <> PLUG JACK 3,5mm MONO ??,?m - UNSHIELDED/SHIELDED - PUR +180°C
	
FU.RSC.CABL.01.015-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 1,5m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.030-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 3,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.050-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 5,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.100-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 10,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.150-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 15,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	

Part number	Description
FU.RSC.CABL.01.200-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 20,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.300-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 30,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.01.XXX-1	SENSOR-/ACTOR CABLE M8 4PF <> FREE END 0,2..40,0m - SHIELDED STRAIGHT - PUR RAL7021 - -25°..+90°C
	
FU.RSC.CABL.02.015-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END 1,5m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.030-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END 3,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.050-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END 5,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.100-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END 10,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.150-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END 15,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	

Part number	Description
FU.RSC.CABL.02.200-1	SENSOR-/ACTOR CABLE M8 4PF 90°<> FREE END 20,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.300-1	SENSOR-/ACTOR CABLE M8 4PF 90°<> FREE END 30,0m - SHIELDED - PUR RAL7021 - -25°..+90°C IP65
	
FU.RSC.CABL.02.XXX-1	SENSOR-/ACTOR CABLE M8 4PF 90° <> FREE END xx, xm (0,2...20m) - SHIELDED - PUR RAL7021 - -25°..+90° IP65
	
FU.RSC.CABL.05.003-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 0,3m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.006-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 0,6m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.015-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 1,5m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.030-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 3,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.050-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 5,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	

Part number	Description
FU.RSC.CABL.05.100-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 10,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.150-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 15,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.200-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 20,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.300-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 30,0m SHIELDED STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.05.XXX-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF SHIELDED STRAIGHT L: 0,2...40m - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.003-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 0,3m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.006-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 0,6m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.015-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 1,5m SHIELDED - PUR BLACK -25°..+80°C IP65
	

Part number	Description
FU.RSC.CABL.06.030-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 3,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.050-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 5,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.100-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 10,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.150-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 15,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.200-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 20,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.300-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 30,0m SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.RSC.CABL.06.XXX-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° xx, xm (0,2...20m) SHIELDED - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.01.015-1	SAC-4P-1,5-PUR/M 8FS (1681842) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 1,5m - STRAIGHT
	

Part number	Description
FU.SRL.CABL.01.030-1	SAC-4P-3,0-PUR/M 8FS (1681855) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 3,0m - STRAIGHT
	
FU.SRL.CABL.01.050-1	SAC-4P-5,0-PUR/M 8FS (1681868) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 5,0m - STRAIGHT
	
FU.SRL.CABL.01.100-1	SAC-4P-10,0-PUR/M 8FS (1683484) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 10,0m - STRAIGHT
	
FU.SRL.CABL.01.150-1	SAC-4P-10,0-PUR/M 8FS (1683484) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 10,0m - STRAIGHT
	
FU.SRL.CABL.01.200-1	SAC-4P-20,0-PUR/M 8FS (1683507) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 20,0m - STRAIGHT
	
FU.SRL.CABL.01.300-1	SAC-4P-M 8FS/PUR/30.0 (1697771) - SENSOR-/ACTOR CABLE M8 4PF <> FREE END 30,0m - STRAIGHT
	
FU.SRL.CABL.05.003-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 0,3m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.015-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 1,5m STRAIGHT - PUR BLACK -25°..+80°C IP65
	

Part number	Description
FU.SRL.CABL.05.030-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 3,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.050-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 5,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.100-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 10,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.150-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 15,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.200-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 20,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.05.300-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 30,0m STRAIGHT - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.06.030-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 3,0m - PUR BLACK -25°..+80°C IP65
	
FU.SRL.CABL.06.050-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 5,0m - PUR BLACK -25°..+80°C IP65
	

Part number	Description
FU.SRL.CABL.06.100-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 10,0m - PUR BLACK - 25°..+80°C IP65
	
FU.SRL.CABL.06.150-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 15,0m - PUR BLACK - 25°..+80°C IP65
	
FU.SRL.CABL.06.200-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 20,0m - PUR BLACK - 25°..+80°C IP65
	
FU.SRL.CABL.06.300-1	SENSOR-/ACTOR CABLE M8 4PM <> M8 4PF 90° 30,0m - PUR BLACK - 25°..+80°C IP65
	

Software Licenses

FASFTWDD01	DATA DUMP - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION (DELIVERED WITH SDT200SD)
	
FASFTWR270VI	VirtualSDT270 - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
	
FASFTWRAP01	RapsodyBox - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
	

Part number	Description
FASFTWSDTUPD	SDTUpdater - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
	
FASFTWSR01	Sherlog Reporter - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
	
FASFTWTTR01	Tanktest Reporter - SOFTWARE PC - INSTALLATION 1 PC - FREE LICENSE, NEED REGISTRATION/ACTIVATION
	
FASFTWUAS3-BEAR	UAS3 - ACTIVATION KEY BEARING TOOLBOX W/ DATABASE (S/N UAS3 LICENCE REQUIRED)
	
FASFTWUAS3M	UAS3 - MASTER LICENSE (1 user + network)
	
FASFTWUAS3S	UAS3 - SINGLE ADDITIONAL USER (NEEDS MASTER LICENSE)
	
FASFTWUASLI00	UAS Lite (FREE OF CHARGE)
	

Part number	Description
Mobile Apps	
FASFTWLRP000	LEAKReporter - Mobile App
	
FASFTWSRP000	SHERLOGReporter - Mobile App
	
Flexible Sensors	
FS.FLX2.R10.001-03	FLEXID2 - FLEX AIRBONE SENSOR W/ REMOVABLE SENSOR 10mm (W/O CABLE, L=550mm)
	
FS.FLX2.R16.001-03	FLEXID2 - FLEX AIRBONE SENSOR W/ REMOVABLE SENSOR 16mm (W/O CABLE, L=550mm)
	
FS.SEN.AIRS.001-01	AIRsense - US SENSOR W/ ACC & PRECISION INDICATOR
	
FU.SEN.UTS.001-01	ULTRAsense US SENSOR
	
FUFLEXEX1	FLEXIBLE 550mm BNC ATEX W/ REMOVABLE SENSOR 16mm & EXTENSION
	
FAFLEXH820-01	FLEX HANDLE 820mm FOR REMOVABLE SENSOR (SDT)
FAFLEXSENS16RA	REMOVABLE SENSOR 16mm ATEX FOR FLEX
FAFLEXTUBE-06	HANDLE 400mm FOR FLEX ATEX
FAFLEXTUBE-07	HANDLE 100mm FOR FLEX ATEX

Part number	Description
-------------	-------------

Flexible Sensors Cables

FUCABLMPLE17MRJ45-01	NETWORK CABLE LE17F - RJ45 2,5m (SDT270)
----------------------	--



FUCABLMPLE17MRJ45-02	NETWORK CABLE LE17F - RJ45 5,0m (SDT270)
----------------------	--



FUCABLMPLE17MRJ45-10	NETWORK/SERIAL CABLE LE17F - RJ45/RS232 2,5m (SDT270)
----------------------	---



SICABUSBAUSBMM	CABLE USB TYPE A - B5 MINI
----------------	----------------------------



Contact Probes

FU.SEN.RS2N.001-01	RS2NL100 NEEDLE CONTACT PROBE W/O CABLE (NL=82mm)
--------------------	---



FU.SEN.RS2N.002-01	RS2NL300 NEEDLE CONTACT PROBE W/O CABLE (NL=275mm)
--------------------	--




FU.SEN.RS2N.003-01	RS2NL500 NEEDLE CONTACT PROBE W/O CABLE (NL=470mm)
--------------------	--



Part number	Description
FUSOND270A-01-A	RS1NL100 NEEDLE CONTACT PROBE ATEX (L=82mm) W/O CABLE
	
FUSOND270A-02-A	RS1NL300 NEEDLE CONTACT PROBE ATEX (L=275mm) W/O CABLE
	
FUSOND270A-03-A	RS1NL500 NEEDLE CONTACT PROBE ATEX (L=470mm) W/O CABLE
	

Threaded Sensors




FU.SEN.LUBE.001-01	LUBESens1 w/o CABLE
	
FU.SEN.LUBE.002-01	LUBESens1 IP65 w/o CABLE FOR USE W/ RMB, O4US
	
FU.SEN.RS2T.001-01	RS2T THREADED SENSOR W/O CABLE
	
FU.SEN.RS2T.002-01	RS2T IP65 THREADED SENSOR W/O CABLE
	

Part number	Description
FUSCRS3A-01-A  	THREADED SENSOR RS1T ATEX
Threaded Sensors Accessories	
FU.SEAC.LUB.006-01 	LUBE ADAPTER w/ G-COUPLER (M6 - BSP 1/8")
FUSEACLUBE-03-A 	LUBE ADAPTER FOR USE W/ FUSCRS3-01 (M6 - BSP 1/8")
FUSEACLUBE-04-A 	LUBE ADAPTER BUTTON HEAD Ø16mm or 15mm hex-6 STANDARD PUSH-ON FOR USE W/ FUSCRS3-01
FUSEACLUBE-05-A 	LUBE ADAPTER BUTTON HEAD Ø22mm STANDARD PULL-ON FOR USE W/ FUSCRS3-01
FUSEACMAG-01 	FLAT MAGNETIC FOOT D25x14 M6
FUSEACMAG-02 	CURVED MAGNETIC FOOT D30x23 M6

Part number	Description
FUSEACMP1	MOUNTING PAD - INOX - HEX22 x10mm - (PACK OF 10 PCS)
	
SI.CP2.MMF.073--A	ADAPTER M6 Female - M8 Male INOX
	
SI.CP2.MMF.074--A	ADAPTER M6 Female -1/4" UNF Male INOX
	
SIMSENSCP2MP-01-C	MOUNTING PAD CP2
	
Accelerometer Sensors	
FU.SEN.ACC.001	HS100 ACCELEROMETER, TOP ENTRY 100mV/g, 2 PIN MS CON., M6x1 MALE
	
FU.SEN.ACC.002	HS100I ACCELEROMETER ATEX , TOP ENTRY 100mV/g, 2 PIN MS CON., M6x1 MALE
 	
FU.SEN.ACC.007	HS150 S 100 50 06 ACCELEROMETER MULTI-PURPOSE HIGH TEMP, SIDE ENTRY 100mV/g, 2 PIN MS CONNECTOR, M6
	

Part number	Description
FU.SEN.ACC.011	HS100T ACCELEROMETER W/TEMP OUTPUT, TOP ENTRY 100mV/g - 10 mV/°C, 3 PIN MS CON., M6x1 MALE
	

COMMONSense Sensors

FU.SEN.RSC.001-03	COMMONSense; RSC US DYN 4-20mA M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 561 YY XXXX)
	
FU.SEN.RSC.002-03	COMMONSense; RSC US DYN 4-20mA M8 4PM - AIRBORNE CLOSED - IP65 W/O CABLE (RED - S/N 565 YY XXXX)
	
FU.SEN.RSC.003-03	COMMONSense; RSC US DYN 4-20mA M8 4PM - AIRBORNE OPEN - IP40 W/O CABLE (RED - S/N 566 YY XXXX)
	
FU.SEN.RSC.101-03	COMMONSense; RSC US STAT 4-20mA M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 573 YY XXXX)
	
FU.SEN.RSC.102-03	COMMONSense; RSC US STAT 4-20mA M8 4PM - AIRBORNE CLOSED - IP65 W/O CABLE (RED - S/N 574 YY XXXX)
	
FU.SEN.RSC.103-03	COMMONSense; RSC US STAT 4-20mA M8 4PM - AIRBORNE OPEN - IP40 W/O CABLE (RED - S/N 575 YY XXXX)
	

Part number	Description
FU.SEN.RSIE.001-03 	COMMONSense; RS US IEPE M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 582 YY XXXX)
FU.SEN.RSV.001-03 	COMMONSense; RSV US DYN 0-10V M8 4PM - THREADED SENSOR M6 - IP65 W/O CABLE (RED - S/N 569 YY XXXX)
FU.SEN.RSV.002-03 	COMMONSense; RSV US DYN 0-10V M8 4PM - AIRBORNE CLOSED - IP65 W/O CABLE (RED - S/N 570 YY XXXX)
FU.SEN.RSV.003-03 	COMMONSense; RSV US DYN 0-10V M8 4PM - AIRBORNE OPEN - IP40 W/O CABLE (RED - S/N 571 YY XXXX)

COMMONSense Accessories

FU.RSC.ACC.001-01 	COMMONSense - CONFIGURATION INTERFACE (PC)
Consists of: ABPRODTIME SA.S4-20.PCB.005-01 SI.RSC.MMF.011-01 SI.RSC.MMF.012-01 SICAASR270HDPH-01 SICONPM8-4PF-01-01 SILABELSYST3T-02 SIMM7985M2,5X8 SISHRTUBE02,4/3	LABOUR COST - (min) (1) PCB SENSOR 4-20mA CONF. INTERFACE Iss.02/1732 - ASSEMBLED PCB RSC - CONFIG INTERACE PROTO - CASE BOTTOM 51 x70 x7,9mm - PA12 BLACK SMOOTH/COLOR DYED - 11,06 cm³ RSC - CONFIG INTERACE PROTO - CASE TOP 51 x70 x17,5mm - PA12 BLACK SMOOTH/COLOR DYED - 18,15 cm³ R270 HDPH SMT 4W 1,25mm CABLE ASSEMBLY T4033014041-000 M8 PANEL CONN 4PF SOLDER BUCKET 4A/30V -40° ..+85°C TE CON. LABEL SYST 3 T-LOC "SDT" (NEW LOGO) - VINYL + LAMINAAT - EXTRA PERM - 82x53mm - RUGSLIT DIN7985H- M2,5x8-4,8-H-Zn (M2,5x8 PAN HEAD PHILLIPS) B-EX 240/30 HEATSHRINK TUBE Ø2,4/1,2mm BLACK L=30mm (PER 1000PCS) (0739 0110 010)

Part number	Description
FU.RSC.ACC.001-02	COMMONSense - CONFIGURATION INTERFACE (PC - USB/M8/LE7)
	
ABPRODTIME	LABOUR COST - (min) (1)
FAR270ACCB	R200/R270/LBX/R340 - LEMO 7 - BLACK ASSEMBLY W/ NUT, WASHER & CABLE ASS.
SA.S4-20.PCB.005-02	PCB SENSOR 4-20mA CONF. INTERFACE Iss.02/1755 - ASSEMBLED PCB
SI.RSC.MMF.011-02	RSC - CONFIG INTERACE - CASE 55,9 x46,0 x23,5mm - PA12 BLACK SMOOTH/COL DYED - 18,16cm ³
SI.RSC.MMF.012-02	RSC - CONFIG INTERACE - CASE TOP 23,5 x46,0 x12,1mm - PA12 BLACK COL. DYED - 4,80cm ³
SIGLUELOC408-20	LOCTITE 408 - INSTANT ADHESIVE - 20ml - DIFFICULT TO BOND PLASTIC & RUBBER PARTS - LOW BLOOMING
SIGLUELOC431-20	LOCTITE 431 - INSTANT ADHESIVE - 20ml - GENERAL PURPOSE / HIGH VISCOSITY
SIGLUELOC454-20	LOCTITE 454 - GENERAL PURPOSE ADHESIVE GEL - 20g
SILABELSYST3T-02	LABEL SYST 3 T-LOC "SDT" (NEW LOGO) - VINYL + LAMINAAT - EXTRA PERM - 82x53mm - RUGSLIT
SILEDACC010	1282.3000 LED LIGHT GUIDE FOR FRONT PANEL- SPHERICAL Ø2,8/3,2 x 5,7/7,2mm PC CLEAR RoHS MENTOR

Parabolic Sensors

FS.PAR2.005-01	ParaDish2 - PARABOLIC SENSOR (LASER CLASS 2, LASER PWR <1mW), L-BOX
	
FU.ACC.TBX.001-1	TOOLBOX W/ INLAY FOR PARABOLIC SENSOR - TANKTEST SENSORS - ACCESORIES
FU.PAR2.005--01	PARABOLIC SENSOR - PARADISH2 (LASER CLASS 2)

FS.PAR2.006-01	ParaDish2 - PARABOLIC SENSOR ATEX (LASER CLASS 2, LASER PWR <1mW) w/ L-BOX
	
FU.ACC.TBX.001-1	TOOLBOX W/ INLAY FOR PARABOLIC SENSOR - TANKTEST SENSORS - ACCESORIES
FU.PAR2.006--01	PARABOLIC SENSOR - PARADISH2 (LASER CLASS 2) - ATEX

Transmitters

FS.TSO1.001	T-Sonic1 - US EMITTER DEVICE w/ BATTERIES INCLUDED (TSO1)
	
FA.TSO1.DM	T-Sonic1 - USER GUIDE W/ DATASHEET
FU.TSO1.001	T-Sonic1 - US EMITTER DEVICE w/o BATTERIES
SA.TSO1.CBX.001-01	TSO1 CARDBOARD PACKING BOX W/ FOAM
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA

Part number	Description
FS.TSO9.001-03	T-Sonic9 - US EMITTER DEVICE w/ BATTERIES INCLUDED
	
Consists of:	
FA.TSO9.DM	T-Sonic9 - USER GUIDE W/ DATASHEET
FA.TSO9.DVP	TSO9 - DEVICE PROTECTION EPDM BLACK W/ MAGNETICS
FA.TSO9.MMF.005-01	TSO1/TSO9 - ATTENUATION TOOL FUNCTIONAL TEST
FAHOLSAC-01	SHOULDER STRAP W/ LOGO SDT
FU.TSO9.001-03	T-Sonic9 - US EMITTER DEVICE w/o BATTERIES
FU.TSO9.002-02	T-Sonic9 - REMOTE CONTROL w/ BATTERIE
SA.TSO9.CBX.001-01	TSO9 CARDBOARD PACKING BOX W/ FOAM
SIBAT1,5VAA-AA	BATTERY ALKALINE 1,5V AA
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI

Transmitters Accessories

FA.TSO9.DVP	TSO9 - DEVICE PROTECTION EPDM BLACK W/ MAGNETICS
	
Consists of:	
SF.TSO9.MMF.005-01	TSO9 - PROTECTION HOLSTER EPDM 60° BLACK - 156,8 x118,0 x49,9mm - 180,1 cm ³ - TOOLING COST
SI.TSO9.MMF.005-01	TSO9 - PROTECTION HOLSTER EPDM 60° BLACK W/ MAGNETICS - 156,8 x118,0 x49,9mm - 180,1 cm ³
SIMAGNR20/10X6	RM-20x10x06-N NEODYMIUM RINGMAGNET N44 NICKEL Ø20 xØ10x H=6,0 (± 0,1mm) - 7,0kg


FA.TSO9.MMF.005-01	TSO1/TSO9 - ATTENUATION TOOL FUNCTIONAL TEST
	

FU.TSO9.002-02	T-Sonic9 - REMOTE CONTROL w/ BATTERIE
	

Cables

FUCALMPSTWSUB	CABLE RS232- STEWART<> SUBD9F, L= 1.5 m
	

FUCALMPSUBUSB	CABLE USB1.1 TO SERIAL DB9M W/SOFT
	

Part number	Description
FUCABLPWRC7EU-01	POWER CORD 1,5m C7F - EURO
	
FUCABLPWRC7UK-01	POWER CORD 1,8m C7F - UK
	
FUCABLPWRC7US-01	POWER CORD 1,8m C7F - US
	
FUCABLSPLE7BNC18	CABLE SPIRAL- LEMO 7P<> BNC, L= 6/18dm
	
FUCABLSPLE7BNC22	CABLE SPIRAL- LEMO 7P<> BNC, L=10/22dm FOR FUFLEX82* / FUFLEXEX1
	
FUCABLSPLE7LE7-10	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR RS1, RS2, LUBEsense1, FLX2
	

Headphones


FUHDPH-21	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY NECKBAND
	
SICABLHDPH.03-01	Consists of: CABLE FOR HEADPHONE HTS2B W/ 1/4" STEREO

Part number	Description
FUHDPH-22	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY HEADBAND
	
FUHDPH-23	HEADPHONE 3M PELTOR CH-3 FLX2 LISTEN ONLY W/ HELMET ATTACH
	
FUHDPH-4	LOUDSPEAKER EXT. SDT170/200/270/340
	
FUHDPH-8	HEADPHONE PELTOR WS HEADSET XP (COMMUNICATION BLUETOOTH)
	
FUHDPHSET-10	HEADPHONE BT w/ PROTECTION HELMET (WHITE)
	

Batteries

FU.R340.BPS-03	R340 BATTERY PACK STANDARD - 4,8V 3600mAh NiMh
	
FUBATTR101	BATTERY PACK SDT101
	

Part number	Description
FUBATTR150FW2	BATTERY PACK SDT150 FRIWO
	
FUBATTR170-02	BATTERY PACK SDT170 - Iss.02
	
FUBATTR270	BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh w/ cable assembly
	
FUBATTR270A	BATTERY PACK SDT270 / SDT200 ATEX- 4,8V 4000mAh NiMh w/ cable assembly
 	
FUBATT008	BATTERY SDT8 12V/1.2Ah
	
FUBATT200	BATTERY PACK 200mW
	
SIBAT1,2VNIMH-AA-03	NiMh RECHARGEABLE BATTERY 1,2V 2600mAh HR6 (AA) Ø14,5x50mm LOW SELF DICHARGE - VARTA 5716
	
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
	

Part number	Description
Battery Chargers	
FU.R340.BDS-02	R340 BATTERY PACK DOCKING STATION
	
FU.R340.PS1-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - EU
	
FU.R340.PS2-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - US
	
FU.R340.PS3-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - UK
	
FU.R340.PS4-01	R340 PS 30W FOR BATTERY DOCKING STATION - IEC C8 POWER INLET (REQUIRES POWER CABLE)
	
FU.R340.PS5-01	R340 WALL PLUG PS 30W FOR BATTERY DOCKING STATION - AUS
	
FUBATTAD8	BATTERY CHARGER ADAPTER SDT8
	

Part number	Description
FUPWSP8EU	BATTERY CHARGER SDT8 - 100-240 EU
	
FUPWSP8UK	BATTERY CHARGER SDT8 - 100-240 UK
	
FUPWSP8US	BATTERY CHARGER SDT8 - 100-240 US
	
FUPWSPUN-01	UNIVERSAL BATTERY CHARGER (SDT170, 200, 270) W/O CORD (FUCABLPWRC7xx)
	
ABPRODTIME	LABOUR COST - (min) (1)
SAPCBUPSL--05	PCB UNIVERSAL BATTERY CHARGER Iss.05/1313 - FR4-35µm-2L 127,05 x 67,1mm - ASSEMBLED PCB
SICASUPSL-03	CASE "UPSL" COVER & BOTTOM 135x74x30,5mm - PC/ABS EMERGE 757 BLACK - Insert With logo SDT
SICONPWR0721-03	2570 APPLIANCE INLET C8 - SNAP-IN, FRONT W/ SOLD.LUGS 2,5A 250VAC/7A 125VAC RoHS (SCHURTER 4300.0102
SILABELUPSL-05	LABEL "FUPWSPUN-01" (CSA) - POLYESTER PERM. AD.-50x40mm- BLACK, WHITE PRINT - P05AA04D - UL CONFORM
SILEDACC003	1293.1700 LED LIGHT GUIDE FOR FRONT PANEL- COUNTERSINK Ø 5,0/4,2 x22,4mm RoHS MENTOR
SIPSSDT170LEAD1	LEAD FRIWO 3P FOR SDT170 BATTERY LOADER
SISHRTUBE04,8/2	SAM 4,8 HEATSHRINK TUBE Ø4,8/2,4mm BLACK 1,22m (0603 0051 010)
SIWIVOBST75RED	4510042 H05V-K 0,75mm² RED FLEX. WIRING CABLE 300/500V PVC

TankTest Sensors

FU.TTSY.TTS2.003-02	CAMLOCK 2" W/ 2x SENSOR TTS2 Ex TANK TEST - LEMO7PM (RED/ BLACK), L= 50dm - VITON
	
FA.TTSY.MMF.003-01	KAMLOCK 2" FEMALE W/ 2x CABLE GLAND + KAMLOCK 1" MALE + MOUNTING HARDWARE
FU.ACC.TBX.001-1	TOOLBOX W/ INLAY FOR PARABOLIC SENSOR - TANKTEST SENSORS - ACCESORIES
FU.TTSY.TTS2.001	SENSOR TTS2 Ex TANK TEST BLACK, L= 50dm - VITON W/ LEMO (S/N 014 YY XXXX - 1 LINE)
FU.TTSY.TTS2.002	SENSOR TTS2 Ex TANK TEST RED, L= 50dm - VITON W/ LEMO (S/N 114 YY XXXX - 2 LINES)
SI.TTSY.MMF.004--B	RUBBER TT SENSOR PROTECTION Ø 39,8/31,8 x35,0mm NBR 70° ±5° Shore, BLACK

Part number	Description
FU.TTSY.TTS2.013-01	CAMLOCK 2" W/ 2x SENSOR R340 TTS2 TANK TEST - LEMO7PM (RED/BLACK), L= 50dm - VITON
	Consists of: KAMLOCK 2" FEMALE W/ 2x CABLE GLAND + KAMLOCK 1" MALE + MOUNTING HARDWARE TOOLBOX W/ INLAY FOR PARABOLIC SENSOR - TANKTEST SENSORS - ACCESORIES SENSOR R340 TTS2 TANK TEST BLACK, L= 50dm - VITON W/ LEMO (S/N 024 YY XXXX - 1 LINE) SENSOR R340 TTS2 TANK TEST RED, L= 50dm - VITON W/ LEMO (S/N 124 YY XXXX - 2 LINES) RUBBER TT SENSOR PROTECTION Ø 39,8/31,8 x35,0mm NBR 70° ±5° Shore, BLACK
FA.TTSY.MMF.003-01 FU.ACC.TBX.001-1 FU.TTSY.TTS2.011 FU.TTSY.TTS2.012 SI.TTSY.MMF.004--B	

FUTTACSETKA2FSEN	CAMLOCK 2" W/ 2 TT SENSORS (BLACK & RED) - NITRILE
	Consists of: CAMLOCK 2" FEMALE W/ CAMLOCK 1" MALE & 2 STUFFING BOXES SENSOR Ex TANK TEST BLACK, L= 50dm - NITRILE W/ BNC SENSOR Ex TANK TEST RED, L= 50dm - NITRILE W/ BNC
FUTTPKA2FKA1M FUTTSEB50N--02 FUTTSEB50N--02	

FUTTACSETKA2FSEV	CAMLOCK 2" W/ 2 TT SENSORS (BLACK & RED) - VITON
	Consists of: LABOUR COST - (min) (1) CAMLOCK 2" FEMALE W/ CAMLOCK 1" MALE & 2 STUFFING BOXES SENSOR Ex TANK TEST BLACK, L= 50dm - VITON W/ BNC SENSOR Ex TANK TEST RED, L= 50dm - VITON W/ BNC
ABPRODTIME FUTTPKA2FKA1M FUTTSEB50V--02 FUTTSEB50V--02	

TankTest Accessories

FABALTT	BALLONS TANK TEST (100pcs/pack)
	

FAORING48X6	SET O-RING 48x6 NBR (5pcs) FOR TTEST CONNECTION TUBE
	Consists of: O-RING Ø48,0 x6,0mm NBR 70° TEMP -30°...+120°C
SIORING48X6	

FATTACLEV GASL	SLEEVE FOR LEVEL GAUGE TTEST
	Consists of: LABOUR COST - (min) (1) TANKTEST SLEEVE GAUGE BODY DIN933- M10x25 - INOX 307 000 100.100 ENSAT-SB M10x10 THREADED INSERT - SELF-TAPPING (KKV) TANKTEST SLEEVE GAUGE TIP NYLON
ABPRODTIME SAMTTLEV GAGSL1 SIMM933A2M10X25 SIMMIK307010040 SITTELEV GAGESL2	

Part number	Description
FS.MTT.ACC1-01	MTT - LEAK SIMULATOR W/ 6 LEAKS AND TUBE (SANS TOOLBOX)
	
FS.MTT.ACC2-01	MTT - LEAK SIMULATOR W/ 6 LEAKS AND TUBE (w/ TOOLBOX)
	
FS.MTT.ACC3-01	MTT - LEAK SIMULATOR TINY VERSION W/ 6 LEAKS (SANS TOOLBOX)
	
FU.MTT.ACC1.010-01	MTT - LEAK SIMULATOR - DIGITAL MANOMETER ATEX W/ QUICK COUPLING (ACCESSORY)
	
FU.MTT.ACC1.012-01	MTT - LEAK SIMULATOR - DIGITAL MANOMETER W/ QUICK COUPLING (ACCESSORY)
	
FU.TTSY.CABL.001-01	SENSOR TTS2 TANK TEST - EXT. CABLE SET 2x 5,0m VITON LEMO7F/LEMO7M
	
FUCABLPWRTTAD-01	TANKTEST POWER CABLE ADAPTOR (VACUUMUNIT GEV)
	
ABPRODTIME	LABOUR COST - (min) (1)
SICABBOOTAI1,5-3	T1515ET WIRE TERMINAL 1,5mm ² BLACK
SICABXVB3G15	H07RN-F 3G1,5 - FLEXIBLE FEEDER CABLE 3G1,5 NEOPRENE BLACK 450/750V -25°...+55°C
SICOCAPWREUF-03	14502 MAIN PWR CONNECTOR FOR CABLE 16A 230V 2P+PE 6h IP54 (CONNECTOR ProTop - MENNEKES)
SICOCAPWREUM-02	MAIN PWR PLUG 2PM+PE EU CABLE PRT, BLACK, RUBBER IP44 (CEBEO ART 423.521)

Part number	Description
FUPUMPVACGP45-02 	TANK TEST PUMP Ex-PROOF 45m³/h 230V 50Hz MONO (ATEX CERTIFIED)
FUPUMPVACSA 	TANK TEST PUMP NON Ex-PROOF
FUTTACSETRUBS 	TANKTEST - RUBBER STOPPER SET Consists of: TANKTEST RUBBER STOPPER Ø8 - 12mm (13D) (SET 4Pcs) TANKTEST RUBBER STOPPER Ø14 - 18mm (18D) (SET 4Pcs) TANKTEST RUBBER STOPPER Ø16 - 21mm (21D) (SET 2Pcs) TANKTEST RUBBER STOPPER Ø18 - 24mm (24D) (SET 2Pcs) TANKTEST RUBBER STOPPER Ø22 - 27mm (27D) (SET 2Pcs) TANKTEST RUBBER STOPPER Ø26 - 32mm (31D) (SET 2Pcs) TANKTEST RUBBER STOPPER Ø34 - 41mm (41D) TANKTEST RUBBER STOPPER Ø36 - 44mm (45D) TANKTEST RUBBER STOPPER Ø47 - 55mm (54D) TANKTEST RUBBER STOPPER Ø50,5 - 59,5mm (60D) TANKTEST RUBBER STOPPER Ø55 - 65mm (65D)(SET 2Pcs) TANKTEST RUBBER STOPPER Ø41 - 49mm (49D) TANKTEST RUBBER STOPPER Ø29 - 35mm (34D) T2 EVOLUTION PLASTICASE BLUE 015/YELLOW 03 FASTENERS (251 x181x80)
FUTTACSETRUBS-01 	TANKTEST - RUBBER STOPPER SET "SERVICE STATION" Consists of: TANKTEST RUBBER STOPPER Ø26 - 32mm (31D) (SET 3pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø34 - 41mm (41D) (SET 3pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø36 - 44mm (45D) (SET 3pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø47 - 55mm (54D) (SET 3pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø50,5 - 59,5mm (60D) (SET 2pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø55 - 65mm (65D) (SET 2pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø41 - 49mm (49D) (SET 3pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø29 - 35mm (34D) (SET 3pcs - KIT SERVICE STATION) BOUCHON TT Ø71 - 83mm (SET 2pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø94 - 107mm (SET 2pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø87 - 100mm (SET 2pcs - KIT SERVICE STATION) TANKTEST RUBBER STOPPER Ø60 - 70mm (70D) (SET 2pcs - KIT SERVICE STATION) BOUCHON TT Ø29 - 35mm (SET 3pcs - KIT SERVICE STATION) BOUCHON TT Ø64,5 - 75,5mm (SET 2pcs - KIT SERVICE STATION) BOUCHON TT Ø79 - 92mm (SET 2pcs - KIT SERVICE STATION) SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM - OBSOLETE !!! REMPLACE PAR FU.R340.TBX.001 INLAY SET FOREX - SYST3T - MTT - RUBBER STOPPER SET "SERVICESTATION" BOX AMERICAINE- 410x310x220(H) INT. - KRAFT 115gr DOUBLE CANNELURE BC (1x SYST3)

Part number	Description
FUTTPICONTUB2 	TANK CONNECTION TUBE 2" - 50cm (KA2" M - G2" F W/ NIPPLE 2" & O-RING 48 x 6)
FUTTPIKA1MKA1M 	CAMLOCK 1" MALE <> CAM 1" MALE FOR PIPE CONNECTION
FUTTPIKA2MG2F 	CAMLOCK 2" M - THREAD G2" F INOX H=62mm
FUTTPIPLI5 	PLASTIC PIPE NON Ex-PROOF 1" TANK TO PUMP L=5m W/O FLAME BUST (2x CAMLOCK 1" FEMALE - INPUT)
FUTTPIPLO5 	PLASTIC PIPE NON Ex-PROOF 1" PUMP EXHAUST L= 5m W/ FLAME BUST (2x CAMLOCK 1" FEMALE- OUTPUT)
FUTTPIRUBI5 	RUBBER PIPE Ex-PROOF 1" TANK TO PUMP L=5m W/O FLAME BUSTER (2x CAMLOCK 1" FEMALE - INPUT)
FUTTPIRUBO5 	RUBBER PIPE Ex-PROOF 1" PUMP EXHAUST L=5m W/ FLAME BUSTER (2x CAMLOCK 1" FEMALE- OUTPUT)
SIOILGEVGP45AT-01 	OIL FOR VACUUM ATEX COMPRESSOR GEV GP45 ATEX - 1L

Part number	Description
SIOILVG100COMP	OIL FOR VACUUM ATEX COMPRESSOR - 1L (BUSCH)
	
SIPIIM400	PRESSURE GAGE 0...1 bar, INOX HOUSE Ø63mm, BACK CENTER G¼", CLASS 1,6
	
SIPIIM401	VACUUM GAGE -1...0 bar, INOX HOUSE Ø63mm, BACK CENTER G¼", CLASS 1,6
	
TankTest Accessories Spareparts	
FU.MTT.ACC1.001-01	MTT - LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.002-01	MTT - LEAK 0,04 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.003-01	MTT - LEAK 0,06 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.004-01	MTT - LEAK 0,10 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	

Part number	Description
FU.MTT.ACC1.005-01	MTT - LEAK 0,16 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.006-01	MTT - LEAK 0,25 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.007-01	MTT - LEAK 0,40 LPM @ 2,0 bar W/ QUICK COUPLING FOR LEAK SIMULATOR ADAPTOR
	
FU.MTT.ACC1.008-01	MTT - LEAK SIMU ADAPTOR 1/4" BSPT BRASS
	
FU.MTT.ACC1.009-01	MTT - LEAK SIMULATOR TUBE W/ SLEEVE (LEAK IN FLUID)
	
FU.MTT.ACC1.011-01	MTT - LEAK SIMULATOR ADAPTOR TINY VERSION
	
Remote Monitoring Box	
FS.RMB.003-01	REMOTE MONITORING BOX SS W/ 12 CHANNEL/SENSOR INTERCONNECTION BOARD
	

Part number	Description
FU.RMB.001-01	REMOTE MONITORING BOX - LEMO
	
FU.RMB.003-01	REMOTE MONITORING BOX SS (304SS) - LEMO
	

Remote Monitoring Box Cables

FU.RMB.CABL.000-XX	RMB - CABLE 7P, LE7F<>LE7M, L= 30,00m MAX W/ CABLE GLAND, FOR RS1T-RS2T, LUBESens1 (SPECIFY REQ. LE
	
FU.RMB.CABL.005-XX	RMB - CABLE 7P, LE7F<>LE7M 90°, L= 9,00m MAX W/ 2x CABLE GLAND, FOR RS1T-RS2T, LUBESens1, RS2A
	
FU.RMB.CABL.010-XX	RMB - CABLE 7P, LE7F<>LE7M IP65, L= 30,00m MAX W/ CABLE GLAND FOR RS2T IP65, LUBESens1 IP65 (length
	
FU.RMB.CABL.020-XX	RMB - CABLE 7P, LE7F<>LE7M IP65 -25°..+150°C, L= 16,00m MAX W/ CABLE GLAND FOR RS2T IP65, LUBESens
	
FU.RMB.CABL.100-XX	RMB - TERMINAL BLOCK PLUG 7P<>LE7M, L= 30,00m MAX W/ CABLE GLAND, FOR RS1T-RS2T (SPECIFY REQ. LENGTH
	

Part number	Description
FU.RMB.CABL.101-XX	RMB - TERMINAL BLOCK PLUG 7P<>LE7M 90°, L= 30,00m MAX W/ CABLE GLAND, FOR RS1T-RS2T (SPECIFY REQ. LE
	
FU.RMB.CABL.102-XX	RMB - TERMINAL BLOCK PLUG 7P<>LE7M 90°, L= 30,00m W/ 2x CABLE GLAND, FOR RS1T-RS2T, LUBESens1, RS2A
	
FU.RMB.CABL.110-XX	RMB - TERMINAL BLOCK PLUG 7P<>LE7M IP65, L= 30,00m MAX W/ CABLE GLAND FOR RS2T IP65, LUBESens1 IP65
	
FU.RMB.CABL.111-XX	RMB - TERMINAL BLOCK PLUG 7P<>LE7M 90° IP65, L= 30,00m MAX W/ CABLE GLAND, FOR RS1T-RS2T (SPEC. REQ.
	
FUCABLMPLE7MLE7FXX-3	RMB - CABLE 7W 7P LE7M 90°<>LE7F, L= 30,0m MAX W/ CABLE GLAND (SPECIFY REQ. LENGTH)
	
FUCABLMPM8LE7FXX-2	CABLE FOR FU.RMB.001 - M8 90° <>LE7F W/ CABLE GLAND, L= xxx dm (TO SPECIFY)
	
Cases	
FU.ACC.TBX.001-1	TOOLBOX W/ INLAY FOR PARABOLIC SENSOR - TANKTEST SENSORS - ACCESORIES
	

Part number	Description
FU.R340.TBX.001-1	TOOLBOX W/ INLAY & DOC HOLDER FOR R200/R270/R340
	
FU.SVU.TBX.001-1	CRYSOUND ACOUSTIC IMAGING CAMERA - TOOLBOX W/ INLAY & DOC HOLDER
	
FU.SVU.TBX.002-1	CRYSOUND ACOUSTIC IMAGING CAMERA SERIE 81** - TOOLBOX W/ INLAY & DOC HOLDER
	
Other Accessories	
FAHOLSAC-01	SHOULDER STRAP W/ LOGO SDT
	
FUSEACAC-01	ACCESSORY KIT FOR ACCELOROMETER HANSFORD
	
FUSEACEDS-02-01	EXTENDED DISTANCE SENSOR (EDS) SDT270 w/ SDT logo
	
FUTOOLSCRDRIV	SCREW DRIVER SET FOR BATTERY COVER (SDT150, SDT8, TSO1, TSO9, CHECKER, R340)
	

Part number	Description
SAMR270CSH-02	SDT270 - CAP FOR SENSOR HOLDER 02
	
SAMR270PISH-02	SDT270 - PRECISION INDICATOR SENSOR HOLDER 02
	
SAMR270RSH-01	SDT270 - RING SENSOR HOLDER 01
	
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm
	
RAPsodyBox	
FS.MBT3.001-02	RAPSODY BOX SET - ULTRASOUND SIGNAL SIMULATOR
	
RAPsodyBox Cables	
SICABUSBAUSBBU-02	CABLE USB 2.0 TYPE A MALE - MICRO B MALE 480Mbps 1,0m
	
Demo Benches	
FS.MBT1.000-01	DEMO UNITS: BENCHES - BEARING & GEARING W/ POWER SUPPLIES EU AND SUITE CASE
	

Part number	Description
FS.MBT1.000-02 	DEMO UNITS: BENCHE - BEARING (blue drive wheel) W/ POWER SUPPLY EU AND SUITE CASE
FS.MBT1.001-01 	DEMO UNITS: BENCHES - BEARING & GEARING W/ POWER SUPPLIES US AND SUITE CASE
FS.MBT1.001-02 	DEMO UNITS: BENCHE - BEARING (blue drive wheel) W/ POWER SUPPLY US AND SUITE CASE
FS.MBT1.001-03 	DEMO UNITS: BENCHE - GEARING W/ POWER SUPPLIES US AND SUITE CASE
FS.MBT1.002-01 	DEMO UNITS: BENCHES - BEARING & GEARING W/ POWER SUPPLIES UK AND SUITE CASE
FS.MBT1.002-02 	DEMO UNITS: BENCHE - BEARING (blue drive wheel) W/ POWER SUPPLY UK AND SUITE CASE
FS.MBT2.000-01 	DEMO UNIT: BENCHE BEARING W/ POWER SUPPLY (EU/US/UK) AND SUITE CASE
FS.SVU.MBT1.001-01 	CRYSOUND - DEMO UNIT: GAS LEAK SIMULATOR W/ AIR PUMP (TOOL CASE)

Trainings

FB.TRLBX.001-01

LIMC – BLOCK 1: INTRODUCTION - 90MIN – EN/FR - BY SDT INT -
TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING



FB.TRLBX.002-01

LIMC – BLOCK 2: LBX / UAS3 CONF - 750MIN - EN/FR - BY SDT INT -
TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING



FB.TRLBX.003-01

LIMC – BLOCK 3: TIPS & TRICKS - 180MIN - EN/FR - BY SDT INT -
TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING



FB.TRLBX.021-01

LIMC – BLOCK 1: INTRODUCTION - 90MIN – EN/FR - BY SDT INT -
TRAINING ON-SITE LIVE – IN-HOUSE TRAINING



FB.TRLBX.022-01

LIMC – BLOCK 2: LBX / UAS3 CONF - 750MIN - EN/FR - BY SDT INT -
TRAINING ON-SITE LIVE – IN-HOUSE TRAINING



FB.TRLBX.023-01

LIMC – BLOCK 3: TIPS & TRICKS - 180MIN - EN - EN/FR - BY SDT INT -
TRAINING ON-SITE LIVE – IN-HOUSE TRAINING



FB.TRLBX.030-01

LIMC - TRAINING EVALUATION / ON-DEMAND - ADDITIONAL
CANDITATE/CERT. - 60MIN - EN - BY SDT INT



FB.TSPWRU.001-01

**POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION -
60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



FB.TSPWRU.002-01

**POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE
FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



FB.TSPWRU.003-01

**POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS
FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



FB.TSPWRU.004-01

**POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS -
60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



FB.TSPWRU.005-01

**POWER USER TRAINING - APPROACHES & CONDITION MONITORING
TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



FB.TSPWRU.006-01

**POWER USER TRAINING - FUNDAMENTALS PRINCIPLES SOUND THEORY
& SOUND BEHAVIOR - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE
TRAINING**



FB.TSPWRU.007-01

**POWER USER TRAINING - ULTRASOUND IN CONDITIONING
MONITORING & INSPECTION - 90min - ONLINE/ON-SITE LIVE - IN-HOUSE
TRAINING**



FB.TSPWRU.008-01

**POWER USER TRAINING - ULTRASOUND APPLICATIONS: LEAK
DETECTION - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING**



Part number	Description
FB.TSPWRU.009-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: VALVES - 45min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.010-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: STEAM TRAPS - 60 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.011-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ELECTRICAL INSPECTIONS - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.012-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: HYDRAULIC SYSTEMS - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.013-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: CONDITION-BASED LUBRICATION - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.014-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ROTATING MACHINERY MONITORING - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.015-01 	POWER USER TRAINING - ULTRASOUND APPLICATIONS: TIGHTNESS TESTING - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.016-01 	POWER USER TRAINING - OPERATING SOFTWARE & INSTRUMENTS- CLASSROOM PRACTICAL SESSION - €60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING

Part number	Description
FB.TSPWRU.017-01 	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - € / 60 min - MANDATORY - ONLINE / ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01 	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE / ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01 	POWER USER TRAINING - EXAM (administrative cost) - ONLINE / ON-SITE LIVE - IN-HOUSE TRAINING
FB.USESS.001 	Ultrasound Essentials 1 - 25 short courses - En - By SDTNA
FB.USESS.002 	Ultrasound Essentials 1 - 25 short courses - Fr - By SDT Int
FB.USINS.001 	US INSPECTOR - LEVEL 1 Certification Training - 2.5 days - En / Fr - By SDT Int - Online / On-site LIVE - Public Training
FB.USINS.xxx 	US INSPECTOR – LEVEL 1 Certification Training – 2.5 days – En / Fr – By SDT Int – On-site LIVE - In-house training
FB.USINS.xxx 	US INSPECTOR – LEVEL 1 Certification Training – 2.5 days – En / Fr – By SDT Int – Online - In-house training

Part number	Description
FB.USINS.002 	US INSPECTOR - LEVEL 2 Certification Training - 2.5 days - En/Fr - By SDT Int - Online/On-site LIVE - Public Training
FB.USINS.005 	US INSPECTOR Sherlog - SDT/IMCS Training Program - By Walter Vervloesem
FBS.TRLBX.000-01 	LIMC - BUNDLE OF 3 BLOCKS -1020min - EN/FR - BY SDT INT - TRAINING ON-LINE/HYBRID - IN-HOUSE TRAINING Consists of: LIMC – BLOCK 1: INTRODUCTION - 90MIN – EN/FR - BY SDT INT - TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING LIMC – BLOCK 2: LBX / UAS3 CONF - 750MIN - EN/FR - BY SDT INT - TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING LIMC – BLOCK 3: TIPS & TRICKS - 180MIN - EN - EN/FR - BY SDT INT - TRAINING ON-LINE/HYBRID – IN-HOUSE TRAINING
FBS.TRLBX.020-01 	LIMC - BUNDLE OF 3 BLOCKS - 1020min - EN/FR - BY SDT INT ON-SITE LIVE - IN-HOUSE TRAINING Consists of: LIMC – BLOCK 1: INTRODUCTION - 90MIN – EN/FR - BY SDT INT - TRAINING ON-SITE LIVE – IN-HOUSE TRAINING LIMC – BLOCK 2: LBX / UAS3 CONF - 750MIN - EN/FR - BY SDT INT - TRAINING ON-SITE LIVE – IN-HOUSE TRAINING LIMC – BLOCK 3: TIPS & TRICKS - 180MIN - EN - EN/FR - BY SDT INT - TRAINING ON-SITE LIVE – IN-HOUSE TRAINING
FBS.TSPWRU.000-01 	POWER USER TRAINING – FULL TRAINING – PU+L1 - ALL SESSIONS AND EXAM INCLUDED – 24H – ONLINE/ON-SITE LIVE – PUBLIC TRAINING Consists of:

Part number	Description
FB.TSPWRU.001-01	POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION - 60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.002-01	POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.003-01	POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.004-01	POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.005-01	POWER USER TRAINING - APPROACHES & CONDITION MONITORING TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.006-01	POWER USER TRAINING - FUNDAMENTALS PRINCIPLES SOUND THEORY & SOUND BAHAVIOR - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.007-01	POWER USER TRAINING - ULTRASOUND IN CONDITIONING MONITORING & INSPECTION - 90min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.008-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: LEAK DETECTION - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.009-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: VALVES - 45min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.010-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: STEAM TRAPS - 60 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.011-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ELECTRICAL INSPECTIONS - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.012-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: HYDRAULIC SYSTEMS - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.013-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: CONDITION- BASED LUBRICATION - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.014-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ROTATING MACHINERY MONITORING - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.015-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: TIGHTNESS TESTING - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.016-01	POWER USER TRAINING - OPERATING SOFTWARE & INSTRUMENTS- CLASSROOM PRACTICAL SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.017-01	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01	POWER USER TRAINING - EXAM (administrative cost) - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING

FBTR-CAT1-UT

Ultrasound ISO CAT I - Training Course and Exam - 32h - by Mobius



FBTR-CAT1-UT-EX

Ultrasound ISO CAT I - Training Exam Only - 2h - by Mobius



FBS.TSPWRU.xxx

POWER USER TRAINING – FULL TRAINING – PU+L1 - ALL SESSIONS AND EXAM INCLUDED – 24H – ONLINE/ON-SITE LIVE – IN-HOUSE TRAINING



Consists of:

FB.TSPWRU.001-01	POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION - 60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.002-01	POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.003-01	POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.004-01	POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.005-01	POWER USER TRAINING - APPROACHES & CONDITION MONITORING TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.006-01	POWER USER TRAINING - FUNDAMENTALS PRINCIPLES SOUND THEORY & SOUND BAHAVIOR - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRA
FB.TSPWRU.007-01	POWER USER TRAINING - ULTRASOUND IN CONDITIONING MONITORING & INSPECTION - 90min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.008-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: LEAK DETECTION - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.009-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: VALVES - 45min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.010-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: STEAM TRAPS - 60 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.011-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ELECTRICAL INSPECTIONS - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.012-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: HYDRAULIC SYSTEMS - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.013-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: CONDITION- BASED LUBRICATION - 90 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAIN
FB.TSPWRU.014-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: ROTATING MACHINERY MONITORING - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE T
FB.TSPWRU.015-01	POWER USER TRAINING - ULTRASOUND APPLICATIONS: TIGHTNESS TESTING - 30 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.016-01	POWER USER TRAINING - OPERATING SOFTWARE & INSTRUMENTS- CLASSROOM PRACTICAL SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.017-01	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01	POWER USER TRAINING - EXAM (administrative cost) - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING

FBS.TSPWRU.xxx**POWER USER TRAINING – FULL TRAINING – ONLY PU - ALL SESSIONS AND EXAM INCLUDED – 2 DAYS – ONLINE – IN-HOUSE TRAINING****Consists of:**

FB.TSPWRU.001-01	POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION - 60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.002-01	POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.003-01	POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.004-01	POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.005-01	POWER USER TRAINING - APPROACHES & CONDITION MONITORING TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.017-01	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01	POWER USER TRAINING - EXAM (administrative cost) - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING

FBS.TSPWRU.xxx**POWER USER TRAINING – FULL TRAINING – ONLY PU - ALL SESSIONS AND EXAM INCLUDED – 2 DAYS – ON-SITE LIVE – IN-HOUSE TRAINING****Consists of:**

FB.TSPWRU.001-01	POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION - 60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.002-01	POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.003-01	POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.004-01	POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.005-01	POWER USER TRAINING - APPROACHES & CONDITION MONITORING TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.017-01	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01	POWER USER TRAINING - EXAM (administrative cost) - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING

FBS.TSPWRU.xxx**POWER USER TRAINING – FULL TRAINING – ONLY PU - ALL SESSIONS AND EXAM INCLUDED – 2 DAYS – ONLINE/ON-SITE LIVE – PUBLIC TRAINING – PER PERSON****Consists of:**

FB.TSPWRU.001-01	POWER USER TRAINING - RELIABILITY IMPROVEMENT INTRODUCTION - 60MIN - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.002-01	POWER USER TRAINING - RELIABILITY CENTERED MAINTENANCE FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.003-01	POWER USER TRAINING - FAILURE MODE, EFFECTS & ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.004-01	POWER USER TRAINING - ROOT CAUSE ANALYSIS FUNDAMENTALS - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.005-01	POWER USER TRAINING - APPROACHES & CONDITION MONITORING TECHNOLOGIES - 60min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.017-01	POWER USER TRAINING - PRACTICAL WORK - FIELD WORK SESSION - €/60 min - MANDATORY - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.018-01	POWER USER TRAINING - IMPLEMENTATION PROCESS - 120 min - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING
FB.TSPWRU.019-01	POWER USER TRAINING - EXAM (administrative cost) - ONLINE/ON-SITE LIVE - IN-HOUSE TRAINING